

European available frequency bands for Shure wireless Preference Frequency bands Belgium/Netherlands

Frequency
start stop preference

BLX (R)			
H8E	518	542	BE
K3E	606	630	
K14	614	638	NL
M17	662	686	

SLX-D			
G59	470	519	
H56	518	562	BE
J53	562	606	
K59	606	650	NL
L56	650	694	
S50	823	832	

QLX-D			
V51	174	216	
G51	470	534	BE
H51	534	598	BE
K51	606	670	NL
L52	632	696	
P51	710	782	
Z18	1785	1805	

ULX-D			
V51	174	216	
G51	470	534	BE
H51	534	598	BE
K51	606	670	NL
L52	632	696	
P51	710	782	
Z18	1785	1805	

Axient Digital			
G56	470	636	BE / NL

GLX-D (R)			
Z2	2400	2483,5	BE / NL

Frequency
Start Stop preference

PSM200			
H2	518	554	BE
K9E	606	638	NL
Q3	748	768	
S5	842	865	

PSM300			
H8E / H20	518	542	BE
K3E	606	630	
K12	614	638	NL
L19	630	654	
S8	823	832	
T11	683	865	

PSM900			
G6E	470	506	
G7E	506	542	BE
K1E	596	632	
L6E	656	692	NL

PSM1000			
G10E	470	542	BE
J8E	554	626	
K10E	596	668	
L8E	626	698	NL

